



Weatherstripping

Windows and doors can be a significant place for air leakage. You can keep your existing doors and windows working efficiently by installing weatherstripping to keep outside air where it belongs – outside.

Follow these four easy steps ↘



step one

Remove old weatherstripping

Before installing, remove old weatherstripping and tighten door hardware. Weatherstripping is most commonly used on the inside of door and window frames.



step two

Cut a piece of weatherstripping

Cut a piece of weatherstripping with a pair of scissors to the length needed. Make sure the door is clean and dry before applying.



step three

Apply weatherstripping

Peel about 4 inches of the paper off the adhesive back, press the end firmly to the door or window and continue to peel and apply the weatherstripping until the length of the door or window is lined. The weatherstripping should be applied where the door comes in contact with the frame.



step four

Secure weatherstripping

Press firmly on the weatherstripping from top to bottom to make sure it is securely fastened to the door or window and will not peel off.



Weatherstripping Tips: Make sure you purchase the proper thickness of weatherstripping.